

End stops | End supports

End stops TS 35	ES 35	ES 35/2/K	ES 35/K/ST
End stops are necessary for preventing movement of components along the rail. They are put in at the beginning and at the end of the rail assembly. Depending on the DIN rail, they differ in the dimensions of the mounting foot and their screw-on or snap-on design.			
	Screw end stop	Screw end stop	Screw end stop
Dimensions			
Dimensions (LxWxH), mm	46 x 7.5 x 32	50 x 8 x 47	50 x 9.5 x 44
Type			
Type	ES 35 BG	ES 35/2/K BG	ES 35/K/ST BG
Cat. no.	2005.2	2826.2	2828.0
Features			
Material	PA 6.6 V2	PA 6.6 V2	PA 6.6 V2
DIN rails	TS 35	TS 35	TS 35
Terminal width, mm	7.5	8	9,5
	Qty. 50	Qty. 50	Qty. 50
End stops TS 32	ES 32	ES 32/2/K	ES 32/2K/ST
			
	Screw end stop	Screw end stop	Screw end stop
Dimensions			
Dimensions (LxWxH), mm	27 x 7.5 x 44	48 x 8 x 49	50 x 9,5 x 44
Type			
Type	ES 32 BG	ES 32/2/K BG	ES 32/K/ST BG
Cat. no.	2004.2	2825.2	2827.0
Features			
Material	PA 6.6 V2	PA 6.6 V2	PA 6.6 V2
DIN rails	TS 32	TS 32	TS 32
Terminal width, mm	7.5	8	9.5
	Qty. 50	Qty. 50	Qty. 50
End support for BKA / KBL	EH 1	EH 2	EH 2-Z
			
	Screw end support	Screw end support	screwless End support
Dimensions			
Dimensions (LxWxH), mm	22 x 7 x 21	22 x 7 x 23	22 x 5 x 23
Type			
Type	EH 1 BG	EH 2 BG	EH 2-Z BG
Cat. no.	2135.2	2136.2	2147.2
Features			
Material	PA 6.6 V2	PA 6.6 V2	PA 6.6 V2
Mounting	Direct mounting	Direct mounting	Direct mounting
Terminal width, mm	7	7	5
Hole diameter, mm	3.5	3.5	-
For terminal	RKB 4	BKA 2,5 BKA 4	BKA 2,5 BKA 4
	Qty. 50	Qty. 50	Qty. 50